

Requirements for Keeper Installation;

If the Keeper Care system is not being connected to a network or internet connection you will need the following. If no network connection is used the Email Manager feature on the Keeper Care system cannot be used. Reports can be read and printed but not emailed.

Please note;

Supplies needed by Customer before Installation;

1. A 110 volt receptacle at the vendor and at the computer (provided by customer at location).
2. A 25' cat 5 cable, needs to be ran from the computer to the keeper, which is supplied by AIS. However if this distance is greater than 25', customers will need to purchase a longer Cat 5 cable. The distance between the keeper and the computer cannot exceed 300 ft.)

If a network or internet connection is being used you will need the following.

1. A cat 5 cable from the network to the computer location. (Supplied by customer)
2. A switch at computer location. (Supplied by customer)
3. A cat 5 cable from the switch to the vendor. (Within 300 feet, supplied by customer)

Person or persons responsible for filling product and loading data into the Keeper should be present during the installation regardless of connection for training purposes.